



**TYLER EATON MORGAN
NICHOLS & PRITCHETT INC.**

INSTRUCTIONS TO INSTALL STENOCAST USB EZ RECEIVER DRIVERS

Download the program from the link below and follow the installation instructions specifically, please. (Do NOT install by running setup.exe file!)

http://www.silabs.com/public/documents/software_doc/drivers/Microcontrollers/Interface/en/CP210x_VCP_Win2K_XP_S2K3.exe

Once the program is downloaded, run the file and follow the installation prompts. When the program has an option to install the driver files (it is an option you choose to select about midway through the process), make sure you select it. Once the program has installed the drivers, the computer must be restarted.

Once the restart is complete, anytime you plug in a Stenocast USB receiver (even if it has not been installed before), it will recognize the device. The reporter will have the Stenocast USB receiver for you to use at the deposition. If it is the first time for using the USB device on a particular computer, please give it a minute or so to assign the drivers (like a flash drive).

It will then assign a com port in the Device Manager under the name: CP210x, CP2101, or CP2102 USB to UART Bridge Controller. It also might say Silicon Labs in front of the device name. Use the com port number listed next to this device as your realtime setting. This com port name can only be viewed in the Device Manager when the receiver is plugged into your computer at the deposition.